

Georgina Ice Palace
Operating Instructions for Hockey Scoreboard – Blue Pad

Game Set up and management

Setup and Run Game

1. Press **"NEW GAME"**
2. Press **"CLEAR"**
3. Press **"1"** to time down ("0" is for time "UP")
4. "PERIOD #" will show. Input the period # (i.e. 1, 2, 3) and press **"ENTER"**
5. "Period Mins" will show. Input length of period using the key pad (ex. 10) and press **"ENTER"**
6. Check that the autohorn is set properly
 - a. Press **"AUTO HORN"**
 - b. Set as **"0"** if horn should sound only at the end of period or insert the # of seconds for the autohorn (i.e. 120 for it to sound every 2 minutes, or 180 for it to sound every 3 minutes)
7. Press **"TIMER RUN"** to start clock
8. Press **"TIMER HOLD"** to stop clock

Starting A New Period

1. Press **"PERIOD"**
2. Select period desired with keypad. Press **"ENTER"**
3. "Period Mins" will show. Input length of period using the key pad (ex. 10) and press **"ENTER"**

Set Auto Horn

1. Press **"AUTO HORN"**
2. Set **"0"** if horn should sound at end of period or insert the # of **seconds** for the auto horn (i.e. 120 for it to sound every 2 minutes input 120, for 3 minutes input 180).

Goals

Put Up a Goal

1. Press **"HOME"** or **"GUEST"** score will increase by one

Correct the Score

1. Press **"RECALL"**
2. Press **"HOME"** or **"GUEST"**
3. **Enter the correct score**
4. Press **"ENTER"**

Show Time of Day:

1. Press **"RECALL"**
2. Press **"TIME OF DAY"**

Penalties

Setup a Penalty

1. Press the **"HOME"** or **"GUEST"** Penalty
2. Press **"ENTER"**
3. Select player number (or leave as 00). Press **"ENTER"**
4. "Penalty Minutes" will appear. Input the length of penalty (ex. 2) in minutes. Press **"ENTER"**
5. Input the # of seconds (ex. 00). Press **"ENTER"**

Cancel a Penalty

1. Press **"RECALL"**
2. Press **"HOME"** or **"GUEST"**
3. Press **"+"** or **"-"** (to select the penalty that you want to remove)
4. Press **"CLEAR"**, penalty will disappear
5. Press **"ENTER"**