

**Georgina Ice Palace**  
**Operating Instructions for Hockey Scoreboard – Green Pad**

**Game Set up and management**

**Setup And Run Game**

1. Press **“NEW GAME”**
2. Press **“PERIOD”** (Blue Button)
3. **“PERIOD #”** will show. Input the period # (i.e. 1, 2, 3) and press **“ENTER”**
4. **“Period Mins”** will show. Input length of period using the keypad (ex. 10) and press **“ENTER”**
5. Press **“1”** to time down (**“0”** is for time **“UP”**)
6. Check that the autohorn is set properly
  - a. Press **“AUTO HORN”**
  - b. Set as **“0”** if horn only at end of period or insert the # of seconds for the autohorn (i.e. 120 for it to sound every 2 minutes, or 180 for it to sound every 3 minutes)
7. Press **“TIMER RUN”** to start clock
8. Press **“TIMER HOLD”** to stop clock

**Starting A New Period**

1. Press **“PERIOD”**
2. Select period desired with keypad. Press **“ENTER”**
3. **“Period Mins”** will show. Input length of period using the key pad (ex. 10) and press **“ENTER”**

**Set Auto Horn**

1. Press **“AUTO HORN”**
2. Set **“0”** if horn should sound at end of period or insert the # of **seconds** for the auto horn (i.e. 120 fit it to sound every 2 minutes input 120, for 3 minutes input 180).

**Goals**

**Put Up A Goal**

1. Press **“HOME”** or **“GUEST”** score will increase by one

**Correct the Score**

1. Press **“HOME”** or **“GUEST”**
2. Press **“CLEAR”**
3. **Enter the new score**
4. Press **“ENTER”**

**Show Time of Day:**

1. Press **“RECALL”**
2. Press **“TIME OF DAY”**

**Penalties**

**Start A Penalty**

1. Press the **“HOME”** or **“GUEST”** Penalty
2. Press **“ENTER”**
3. **“Penalty Minutes”** will appear. Input the length of penalty (ex. 2) in minutes. Press **“ENTER”**
4. Input the # of seconds (ex. 00). Press **“ENTER”**.

**Cancel A Penalty**

1. Press **“RECALL”**
2. Press **“HOME”** or **“GUEST”**
3. Press **“CLEAR”**, penalty will disappear
4. Press **“ENTER”**.